Cyclic oligomers of poly(ether ketone ketone) and their polymerisation by entropy

David Szmalko, Jessirie Dilag, Stuart Bateman, Richard Evans

Funded by the ARC Training centre for Lightweight Automotive Structures (ATLAS)









Background

- Composites are seeing increasing use in aerospace for lightweighting, especially low viscosity, unrecyclable epoxy thermosets
- Poly ether ketone ketone (PEKK) is a high-performance thermoplastic
- PEKK boasts high thermal stability, high strength, high chemical and fire resistance, and lighter weights.





Commercial PEKK synthesis




- PEKK currently produced by Friedel-Crafts acylation, usage limited by high-viscosity polymer
- PEKK products defined by their T/I ratio, the ratio of para and meta links in the polymer, allowing for range of applications

Arkema's Kepstan® PEKK product series							
Series	T/I ratio	T _m	Τ _g	Crystallization speed			
6000	60/40	305°C	160°C	Slow			
7000	70/30	332°C	162ºC	Medium			
8000	80/20	358°C	165°C	Fast			

Entropy Driven Ring Opening Polymerisation (ED-ROP)

- ED-ROP is the polymerisation of large, strainless ring structures called macrocyclic oligomers (MCOs)
- The reaction is driven by the increase in conformational entropy of the linear polymer
- ED-ROP produces no heat or volatiles, can be performed neat, and MCOs are generally lower viscosity than their polymers.




Synthesising MCOs


- Few examples of cyclic PAEKs and their polymerisation, no complete examples of cyclic PEKK nor PEKK polymer from ED-ROP ^{[1], [2]}
- Only one example of PAEK/carbon fibre composites by ED-ROP in-situ polymerisation ^[3]
- Nucleophilic substitution in a pseudohigh dilution environment is the common strategy
- High temperatures, dipolar aprotic solvent and water removal required

 $\cap =$


[2]: Ben-Haida, A., et al., Cyclic oligomers of poly(ether ketone) (PEK): synthesis, extraction from polymer, fractionation, and characterisation of the cyclic trimer, tetramer and pentamer. Journal of Materials Chemistry, 2000. 10(9): p. 2011-2016. [3]: Misasi, J.M., et al., Polyaryletherketone (PAEK) thermoplastic composites via in-situ ring opening polymerisation. Composites Science and Technology, 2021. 201: p. 108534.

m-PEKK MCO synthesis






m-PEKK MCO characterisation: NMR




7


m-PEKK MCO characterisation: NMR




m-PEKK MCO characterisation: MALDI





X-ray crystallography of m-PEKK dimer






X-ray crystallography of p-PEKK dimer







Synthesis of MCOs with T/I blends



Determining T/I from NMR




A commercial comparison




PEKK MCO polymerisation conditions

- No literature concerning PEKK MCOs, but some for the PAEK family
- Alkali and phenolate salts shown in literature to be good initiators, in particular CsF^[4]
- Reaction occurs at ~150°C in solvent, but higher temps required to melt MCOs/chains so they can participate
- Oxygen and moisture sensitive
- Potential interference from dimer, likely due to higher melting point




DSC – comparison



MCO Sample	T _g	
m-PEKK	151°C	
р-РЕКК	172°C	
60/40 PEKK	156°C	
70/30 PEKK	154°C	
80/20 PEKK	162°C	

GPC and Derivatisation

- MCOs are (somewhat) soluble in chloroform
- PEKK only soluble in exotic solvent systems
- Thioketal derivatisation strategy pursued to assess degree of polymerisation ^[5]




BF₃.OEt₂

TFA CHCl₂


HS¹

Derivatised commercial PEKK GPC



Initial polymerisation results

- Multiple small-scale polymerisation runs in DSC pans
- Varying temperature, polymerisation catalyst and amount, MCO type and time
- Some evidence of polymerisation, best results around 300-350°C
- No high MW polymers on any run



Dimer effect

- Appears to impair polymerisation, despite ED-ROP mechanics
- Higher melting point than other MCOs
- Melting point close to degradation point




High vacuum polymerisation




- 0.15g of m-PEKK MCOs (dimer removed)
- Dissolved with 2mol% CsF, sonicated and solvent evaporated
- Dried at 120°C under 10⁻⁵ mbar vacuum for 20 hours
- Heated to 350°C under 10⁻⁵ mbar vacuum for 0.5 hours

GPC of high vacuum experiments



0 30000 60000 90000 120000 150000 180000 210000 240000

MW



Polymer sample	Peak	M _n	M _w	Polydispersity
m-PEKK	20,467 g/mol	21,704 g/mol	38,411 g/mol	1.77
Arkema 6002	37,032 g/mol	18,785 g/mol	45,990 g/mol	2.45

Summary

- Pseudo-high dilution synthesis of MCOs of both m-PEKK and p-PEKK
- Characterisation by NMR, MALDI-ToF and X-ray crystallography
- Adaptation of method to produce PEKK MCOs with varying T/I ratios
- Investigation of polymerisation of MCOs within DSC
- Assessment of degree of polymerisation by GPC of thioketal derivative
- High MW polymer produced under high vacuum conditions
- Continuing work: Polymerisation of MCOs in the presence of carbon fibre



Acknowledgments

A heartfelt thank you to:

- Professors Stuart Bateman and Richard Evans
- Dr. Jessirie Dilag
- ATLAS
- The RMIT chemistry and engineering technical staff
- Dr. Craig Forsyth and the Monash X-ray platform
- Mark Hickey and the CSIRO Manufacturing GPC facility

Thank you for your time

